




US-6890M Parts numbers



US-6890M Parts numbers



US-6890M Parts numbers



US-6890M PART LIST		
PART NO	DESCRIPTION	QTY
6890-1	Start Button	2
6890-2	MCB (PLS-C10)	1
6890-3	Main Case	1
6890-4	Wire Casing	1
6890-5	Regulator (AW20-02B)	1
6890-6	PE Stopper	2
6890-7	Sensor Guide	2
6890-8	Main Body	1
6890-9	Working Plate	2
6890-10	Spring Washer M5	4
6890-11	Screw (6X25)	4
6890-12	Heater Tube	3
6890-13	Heater Board	1
6890-14	Aluminium Foil & Fiber Cushion	1
6890-15	Heater Plate	1
6890-16	Disc Spring M10	4
6890-17	Nut M10	1
6890-18	Fixed Base For Heater	1
6890-19	Screw M10 X 55	4
6890-20	Nut M10	2
6890-21	Guide Rod	1
6890-22	Sliding Rail (LSH20F2N)	1
6890-23	Screw M5X25	5
6890-24	Screw M5X35	4
6890-25	Handle	2
6890-26	Main Cylinder (SAI40X80)	1
6890-27	Main Cylinder Fitting (PSL602)	2
6890-28	Operation Panel	1
6890-29	Pressure Gauge	1
6890-30	Timer (H3CR_A8E)	1
6890-31	Temperature Controller (E5CC-RX2ASM)	1
6890-32	Counter	1
6890-33	E-Stop Button	1
6890-34	Start Button	1
6890-35	Bottom Plate	1
6890-36	Rail (Long)	1
6890-37	Power Supply (HDR-30-24)	1
6890-38	Solid State Relay (CDG1-1DA-25A)	1
6890-39	Terminal Block (IN13SBK)	5
6890-40	Sensor	1
6890-41	Sensor Bracket	1